



Lista de Compatibilidade com a Fonte 45 / 75W

Digite o modelo do seu equipamento em Localizar para facilitar a busca.

Caso não encontre o referido modelo nos contate por favor.

TO1501

Voltagem: 15 volts

Amperagem: 3,65 ampères

Potência: 54,75 watts

Modelos de notebooks compatíveis com este código (194 modelos disponíveis)

Toshiba Dynapad T200, T200CS (Fonte de 55 watts)

Toshiba Libretto 50CT

Toshiba Libretto 70CT

Toshiba Portege 300CT, 320CT

Toshiba Portege 4000

Toshiba Portege 4010

Toshiba Portege 610, 610CT, 620, 620CT

Toshiba Portege 650, 650CT, 660CDT, 660CT

Toshiba Portege 7000

Toshiba Portege 7000CT, 7010CT, 7020CDT, 7020CT

Toshiba Portege 7140CT

Toshiba Portege 7200CT, 7200CTE, 7220CTE

Toshiba Portege T3400C, T3400CT, T3600C, T3600CT (Fonte de 55 watts)

Toshiba Satellite 1400 (55 watts)

Toshiba Satellite 1405 (55 watts)

Toshiba Satellite 1405-S151, 1405-S152 (55 watts)

Toshiba Satellite 1410 (55 watts)

Toshiba Satellite 1410-S105, 1410-S106 (55 watts)

Toshiba Satellite 1410-S173, 1410-S174 (55 watts)

Toshiba Satellite 1415 (55 watts)

Toshiba Satellite 1415-S105, 1415-S106 (55 watts)

Toshiba Satellite 1415-S115 (55 watts)

Toshiba Satellite 1415-S173, 1415-S174 (55 watts)

Toshiba Satellite 1555

Toshiba Satellite 1555CDS

Toshiba Satellite 1800

Toshiba Satellite 1800, 1800-S203, 1800-S204

Toshiba Satellite 1800-S177
Toshiba Satellite 1800-S206, 1800-S207
Toshiba Satellite 1800-S253, 1800-S254, 1800-S256
Toshiba Satellite 1805
Toshiba Satellite 1805, 1805-S154
Toshiba Satellite 1805-S203, 1805-S204
Toshiba Satellite 1805-S207, 1805-S208
Toshiba Satellite 1805-S253, 1805-S254, 1805-S255
Toshiba Satellite 1805-S273, 1805-S274, 1805-S278
Toshiba Satellite 2060, 2065
Toshiba Satellite 2060CDS, 2060CDT, 2065CDS, 2065CDT
Toshiba Satellite 2100, 2105
Toshiba Satellite 2100CDS, 2100CDT, 2105CDS, 2105CDT
Toshiba Satellite 2140, 2180
Toshiba Satellite 2140CDT, 2140XCDS, 2180CDT
Toshiba Satellite 220, 225
Toshiba Satellite 220CDS, 220CS, 220CT
Toshiba Satellite 2210, 2250
Toshiba Satellite 2210CDT, 2210XCDS
Toshiba Satellite 2250CDT, 2250XCDS
Toshiba Satellite 225CDS
Toshiba Satellite 2400
Toshiba Satellite 2400-S201, 2400-S202
Toshiba Satellite 2400-S251
Toshiba Satellite 2405
Toshiba Satellite 2405-S201, 2405-S202
Toshiba Satellite 2410 (55 watts)
Toshiba Satellite 2410-S185 (55 watts)
Toshiba Satellite 2410-S203, 2410-S204 (55 watts)
Toshiba Satellite 2410-S206 (55 watts)
Toshiba Satellite 2415
Toshiba Satellite 2415-S205, 2415-S206
Toshiba Satellite 2500, 2505, 2510, 2515
Toshiba Satellite 2500CDT, 2505CDS, 2505CDT
Toshiba Satellite 2510CDS, 2515CDS, 2530CDS
Toshiba Satellite 2530, 2535
Toshiba Satellite 2535CDS, 2535CDT, 2540CDS, 2540CDT
Toshiba Satellite 2540, 2545
Toshiba Satellite 2545CDS, 2545CDT, 2545XCDD
Toshiba Satellite 2590, 2595
Toshiba Satellite 2590CDS, 2590CDT, 2590XDVD
Toshiba Satellite 2595CDS, 2595CDT, 2595XDVD
Toshiba Satellite 2615, 2655, 2675, 2695
Toshiba Satellite 2615DVD, 2655XDVD, 2675DVD, 2695DVD
Toshiba Satellite 2715
Toshiba Satellite 2715DVD, 2715XDVD
Toshiba Satellite 2755, 2775

Toshiba Satellite 2755DVD, 2755XDVD, 2775XDVD
Toshiba Satellite 2800
Toshiba Satellite 2800, 2800-S201, 2800-S202, 2800-S210
Toshiba Satellite 2805
Toshiba Satellite 2805, 2805-S201, 2805-S202
Toshiba Satellite 2805-S301, 2805-S302
Toshiba Satellite 2805-S401, 2805-S402
Toshiba Satellite 2805-S503, 2805-S603
Toshiba Satellite 300, 305, 310, 315
Toshiba Satellite 300CDS, 305CDS, 305CDT
Toshiba Satellite 310CDS, 310CDT, 315CDS, 315CDT
Toshiba Satellite 320, 325, 330, 335
Toshiba Satellite 320CDS, 320CDT, 325CDS
Toshiba Satellite 330CDS, 330CDT, 335CDS, 335CDT
Toshiba Satellite 4000, 4005, 4010, 4015
Toshiba Satellite 4000CDS, 4000CDT, 4005CDS, 4005CDT
Toshiba Satellite 4010CDS, 4010CDT, 4015CDT, 4015CDS
Toshiba Satellite 4020, 4025, 4030
Toshiba Satellite 4020CDT, 4025CDS, 4025CDT
Toshiba Satellite 4030CDS, 4030CDT
Toshiba Satellite 4060, 4070, 4080, 4085, 4090
Toshiba Satellite 4060CDT, 4070CDT, 4080CDT, 4080XCDT
Toshiba Satellite 4085XCDT, 4090XCDT, 4090XDVD
Toshiba Satellite 4100
Toshiba Satellite 4100XCDT, 4100XDVD
Toshiba Satellite 4260, 4280
Toshiba Satellite 4260DVD, 4280XDVD, 4280ZDVD
Toshiba Satellite 4300
Toshiba Satellite 440CDT, 440CDX, 440CS, 440CT
Toshiba Satellite 445CDT, 445CDX, 460CDT, 460CDX
Toshiba Satellite 4600
Toshiba Satellite 465CDT, 465CDX
Toshiba Satellite 470CDT, 480CDT, 490CDT
Toshiba Satellite 490XCDT
Toshiba Satellite 5005
Toshiba Satellite 5005-S504, 5005-S507, 5005-S508
Toshiba Satellite 5005-S607, 5005-S608
Toshiba Satellite 5105-S501, 5105-S502
Toshiba Satellite 5105-S607, 5105-S608
Toshiba Satellite 5105-S701, 5105-S702
Toshiba Satellite 5105-S901
Toshiba Satellite 5205-S502, 5205-S504 (55 watts)
Toshiba Satellite 5205-S505, 5205-S506 (55 watts)
Toshiba Satellite 5205-S703, 5205-S704 (55 watts)
Toshiba Satellite A10 (55 watts)
Toshiba Satellite A10-5WM (55 watts)
Toshiba Satellite A10-C8M (55 watts)

Toshiba Satellite A10-HVM, A10-REH (55 watts)
Toshiba Satellite A10-S103 (55 watts)
Toshiba Satellite A10-S113 (55 watts)
Toshiba Satellite A10-S127, A10-S128, A10-S129 (55 watts)
Toshiba Satellite A10-S1291 (55 watts)
Toshiba Satellite A10-S167, A10-S168, A10-S169 (55 watts)
Toshiba Satellite A10-S177, A10-S178 (55 watts)
Toshiba Satellite A10-S203 (55 watts)
Toshiba Satellite A10-S403, A10-S403D (55 watts)
Toshiba Satellite A10-SP127, A10-SP1228, A10-SP129 (55 watts)
Toshiba Satellite A10-SP177 (55 watts)
Toshiba Satellite A15 Series (55 watts)
Toshiba Satellite A15-S127, A15-S128, A15-S129 (55 watts)
Toshiba Satellite A15-S1271 (55 watts)
Toshiba Satellite A15-S157, A15-S158, A15-S159 (55 watts)
Toshiba Satellite A15-SP127 (55 watts)
Toshiba Satellite Pro 4260, 4280
Toshiba Satellite Pro 4260DVD, 4280XDVD
Toshiba Satellite Pro 4280ZDVD
Toshiba Satellite Pro 4300
Toshiba Satellite Pro 440, 445, 460, 465
Toshiba Satellite Pro 4600
Toshiba Satellite Pro 470, 480, 490
Toshiba Satellite Pro 6000
Toshiba Satellite Pro 6100 (55 watts)
Toshiba Satellite T1800, T1850, T1850C (Fonte de 55 watts)
Toshiba Small-Business 1400, 1410
Toshiba Small-Business 2400, 2410, 2430
Toshiba Small-Business 6000
Toshiba Small-Business 6100
Toshiba Small-Business A10
Toshiba T6000
Toshiba Tecra 520CDS, 520CDT
Toshiba Tecra 530CDS, 530CDT
Toshiba Tecra 550CDT
Toshiba Tecra 700, 700CS, 700CT, 710CDT
Toshiba Tecra 720, 720CDT, 730CDT, 730XCDT
Toshiba Tecra 740CDT
Toshiba Tecra 750CD, 750CDM
Toshiba Tecra 750CDT, 750DVD
Toshiba Tecra 780CDM, 780CDT, 780DVD
Toshiba Tecra 8000
Toshiba Tecra 8100
Toshiba Tecra 8200
Toshiba Tecra A1
Toshiba Satellite 1400-S151, 1400-S152 (55 watts)
Toshiba Libretto 75, 75CT

Toshiba Libretto 60, 60CT
Toshiba Portege 2000
Toshiba Portege 2010
Toshiba Portege 3500, 3505 Tablet PC
Toshiba Portege A100
Toshiba Portege M100
Toshiba Portege M200 (55 watts)
Toshiba Portege M205 (55 watts)
Toshiba Portege M205-S809, M205-S810 (55 watts)
Toshiba Portege R100
Toshiba Satellite Pro 2100
Toshiba Satellite Pro M10
Toshiba Satellite Pro M10 Small Business (55 watts)
Toshiba Satellite Pro M10-S405, M10-S406 (55 watts)
Toshiba Satellite Pro M15 Series (55 watts)
Toshiba Satellite Pro M15-S405, M15-S406 (55 watts)
Toshiba Satellite 1800-S274
Toshiba Satellite A10-S213
Toshiba Satellite A15-S1291
Toshiba Satellite A15-SP177
Toshiba Satellite R10
Toshiba Satellite R10-S802TD
Toshiba Satellite R15 Series
Toshiba Satellite R15-S822
Toshiba T4500, T4500C, T4600, T4600C (55 watts)
Toshiba Tecra TE2000

CO1512

Voltagem: 18,5 volts

Amperagem: 3,2 ampères

Potência: 59,2 watts

Modelos de notebooks compatíveis com este código (328 modelos disponíveis)

Compaq Armada 110, 110S
Compaq Armada E300
Compaq Armada E500
Compaq Armada E500S
Compaq Armada E700
Compaq Armada M300
Compaq Armada M700
Compaq Armada V300
Compaq Business NoteBook NX7000 (57 watts)
Compaq Evo N1000, N1000C Series
Compaq Evo N1000V

Compaq Evo N1005V
Compaq Evo N110
Compaq Evo N150
Compaq Evo N400c
Compaq Evo N410c
Compaq Evo N600c
Compaq Evo N610c
Compaq Evo N800, N800c, N800v, N800w
Compaq Evo NoteBook 110, 110S
Compaq Presario 2800
Compaq Presario 2800CA, 2800EA, 2800SC
Compaq Presario 2801, 2801AP, 2801CL
Compaq Prosignia 150
Compaq Prosignia 170
Compaq Prosignia 190
Compaq Business NoteBook NC4000 Series
Compaq Business NoteBook NC4010 Series
Compaq Business NoteBook NC6000 Series
Compaq Business NoteBook NW8000 Series
Compaq Business NoteBook NX5000 Series
Compaq Business NoteBook NX7010 Series
Compaq Evo Série N610v
Compaq Evo N620c Series
Compaq Evo NoteBook Série N1000, N1000C
Compaq Evo NoteBook Série N1000V
Compaq Evo NoteBook Série N1005V
Compaq Presario 2800, 2800AP, 2800AP1, 2800AU
Compaq Presario 2800T, 2800TC, 2800US
Compaq Presario 2801EA, 2801SC, 2801TC
Compaq Presario 2802, 2802AP, 2802AP1, 2802EA
Compaq Presario 2802SC, 2802SC, 2802SP, 2802TC
Compaq Presario 2803, 2803AP1, 2803EA, 2803TC
Compaq Presario 2804, 2804AP, 2804AP1
Compaq Presario 2804EA, 2804SC, 2804TC
Compaq Presario 2805, 2805AP, 2805AP1, 2805AU
Compaq Presario 2805EA, 2805TC, 2805US
Compaq Presario 2806, 2806AP, 2806AP1
Compaq Presario 2806CL, 2806EA, 2806SC
Compaq Presario 2807, 2807AP, 2807AP1, 2807EA
Compaq Presario 2808, 2808AP1, 2808EA
Compaq Presario 2809, 2809AP, 2809FR
Compaq Presario 2810, 2810AP, 2810AU, 2810CA
Compaq Presario 2810CA, 2810EA, 2810LA, 2810SC
Compaq Presario 2810T, 2810TC
Compaq Presario 2811, 2811AP, 2811CA, 2811CL
Compaq Presario 2811EA, 2811SW
Compaq Presario 2812, 2812AP, 2812AU

Compaq Presario 2812EA, 2812SP, 2812TC
Compaq Presario 2813, 2813AU, 2813TC
Compaq Presario 2814, 2814AP, 2814AU
Compaq Presario 2815, 2815AP, 2815AU, 2815EA
Compaq Presario 2815LA, 2815SP, 2815TC
Compaq Presario 2816, 2816AP, 2816EA
Compaq Presario 2816KR, 2816TC
Compaq Presario 2817, 2817AR, 2817EA
Compaq Presario 2817FR, 2817KR, 2817TC
Compaq Presario 2818, 2818AP, 2818FR
Compaq Presario 2818KR, 2818TC
Compaq Presario 2819, 2819AP, 2819TC
Compaq Presario 2820, 2820AP, 2820AU, 2820CL
Compaq Presario 2820EA, 2820SC, 2820TC
Compaq Presario 2821, 2821AP, 2821AU
Compaq Presario 2821DE, 2821EA, 2821SC, 2821TC
Compaq Presario 2822, 2822AP, 2822EA, 2822TC
Compaq Presario 2823, 2823AP, 2823AU, 2823TC
Compaq Presario 2824, 2824AP, 2824EA, 2824TC
Compaq Presario 2825, 2825AP, 2825EA, 2825TC
Compaq Presario 2826, 2826AP, 2826EA, 2826TC
Compaq Presario 2827, 2827AP, 2827TC
Compaq Presario 2828, 2828AP, 2828TC
Compaq Presario 2829, 2829AP, 2829TC
Compaq Presario 2830, 2830AP, 2831AU
Compaq Presario 2830EA, 2830SC, 2830TC
Compaq Presario 2831, 2831AP, 2831SC, 2831TC
Compaq Presario 2832, 2832AP, 2832SC, 2832TC
Compaq Presario 2833, 2833TC, 2834, 2834TC
Compaq Presario 2835, 2835AP, 2835EA
Compaq Presario 2836, 2836AP, 2836TC
Compaq Presario 2837, 2837AP, 2837EA, 2837TC
Compaq Presario 2838, 2838AP, 2838TC
Compaq Presario 2839, 2839AP 2839TC
Compaq Presario 2840, 2840AP, 2840TC
Compaq Presario 2841, 2841AP, 2842, 2842AP
Compaq Presario 2843, 2843AP, 2844, 2844AP
Compaq Presario 2845, 2845AP, 2846, 2846AP
Compaq Presario 2850, 2850AP, 2851, 2851AP
Compaq Presario 2852, 2852AP, 2853, 2853AP
Compaq Presario 2854, 2854AP, 2855, 2855AP
Compaq Presario 2856, 2856AP, 2857, 2857AP
Compaq Presario 2858, 2858AP, 2859, 2859AP
Compaq Presario 2860, 2860AP, 2861, 2861AP
Compaq Presario 2862, 2862AP, 2863, 2863AP
Compaq Presario 2864, 2864AP, 2865, 2865AP
Compaq Presario 2866, 2866AP, 2867, 2867AP

Compaq Presario 2868, 2868AP, 2869, 2869AP
Compaq Presario 2870, 2870AP, 2871, 2871AP
Compaq Presario 2872, 2872AP, 2873, 2873AP
Compaq Presario 2874, 2874AP, 2875, 2875AP
Compaq Presario 2876, 2876AP, 2877, 2877AP
Compaq Presario 2878, 2878AP, 2878CL
Compaq Presario 2879, 2879AP, 2879CL
Compaq Presario 2880, 2880CL, 2801, 2801CL
Compaq Presario 2881, 2881CL, 2882, 2882AP
Compaq Presario 2883, 2883AP, 2884, 2884AP
Compaq Presario 2885, 2885AP, 2886, 2886AP
Compaq Presario 2887, 2887AP, 2888, 2888AP
Compaq Presario 2889, 2889AP
Compaq Presario 2890, 2890AP, 2891, 2891AP
Compaq Presario 2892, 2892AP, 2893, 2893AP
Compaq Presario 2894, 2894AP, 2895, 2895AP
Compaq Presario 2896, 2896AP, 2897, 2897AP
Compaq Presario 2898, 2898AP, 2899, 2899AP
Compaq Presario 300 Series
Compaq Presario 305 Series
Compaq Presario 306 Series
Compaq Presario x1000 Series
Compaq Presario x1001, x1001US, x1002, x1002US
Compaq Presario x1005, x1005EA, x1005LA
Compaq Presario x1006, x1006EA, x1007, x1007EA
Compaq Presario x1010AL, x1010CA, x1010EA, x1010US
Compaq Presario x1011, x1011AL
Compaq Presario x1012, x1012AL, x1012EA, x1012QV
Compaq Presario x1015, x1015US, x1016, x1016EA
Compaq Presario x1020, x10120EA, x1020US
Compaq Presario x1018, x1018CL
Compaq Presario X1021, X1021AP, X1022, X1022AP
Compaq Presario x1023, x1023AP
Compaq Presario x1026, x1026AP, x1027, x1027AP
Compaq Presario x1028, x1028AP, x1028CL
Compaq Presario x1029, x1029AP
Compaq Presario x1030, x1030AP, x1030US
Compaq Presario x1031, x1031AP, x1032, x1032AP
Compaq Presario x1033, x1033AP, x1034, x1034AP
Compaq Presario x1035, x1035AP, x1036, x1036AP
Compaq Presario x1037, x1037AP, x1038, x1038AP
Compaq Presario x1040, x1040AP, x1040US
Compaq Presario x1041, x1041AP, x1042, x1042AP
Compaq Presario x1043, x1043AP, x1044, x1044AP
Compaq Presario x1045, x1045AP, x1046, x1046AP
Compaq Presario x1047, x1047AP, x1048, x1048AP
Compaq Presario x1049, x1049AP

Compaq Presario x1050, x1050AP, x1050CA, x1050US
Compaq Presario x1051, x1051AP, x1052, x1052AP
Compaq Presario x1053, x1053AP, x1054, x1054AP
Compaq Presario x1055, x1055AP, x1056, x1056AP
Compaq Presario x1057, x1057AP
Compaq Presario x1058, x1058AP, x1058CL
Compaq Presario x1060, x1060AP, x1061, x1061AP
Compaq Presario x1062, x1062AP, x1063, x1063AP
Compaq Presario x1064, x1064AP, x1065, x1065AP
Compaq Presario x1066, x1066AP, x1067, x1067AP
Compaq Presario x1068, x1068AP, x1069, x1069AP
Compaq Presario x1070, x1070AP, x1071, x1071AP
Compaq Presario x1072, x1072AP, x1073, x1073AP
Compaq Presario x1074, x1074AP, x1075, x1075AP
Compaq Presario x1076, x1076AP, x1077, x1077AP
Compaq Presario x1078, x1078AP, x1079, x1079AP
Compaq Presario x1080, x1080AP, x1081, x1081AP
Compaq Presario x1082, x1082AP, x1083, x1083AP
Compaq Presario x1084, x1084AP, x1085, x1085AP
Compaq Presario x1086, x1086AP, x1087, x1087AP
Compaq Presario x1088, x1088AP, x1089, x1089AP
Compaq Presario x1090, x1090AP, x1091, x1091AP
Compaq Presario x1092, x1092AP, x1093, x1093AP
Compaq Presario x1094, x1094AP, x1095, x1095AP
Compaq Presario x1096, x1096AP, x1097, x1097AP
Compaq Presario x1098, x1098AP, x1099, x1099AP
Compaq Presario x1100 Series
Compaq Presario x1105, x1105EA
Compaq Presario x1110, x1110EA
Compaq Presario x1115, x1115EA
Compaq Presario x1140, x1140EA
Compaq Presario x1155, x1155EA
Compaq Presario x1200 Series
Compaq Presario x1201, x1201AP, x1201US
Compaq Presario x1206, x1206AP, x1207, x1207AP
Compaq Presario x1204, x1204AP, x1205, x1205AP
Compaq Presario x1206, x1206AP, x1207, x1207AP
Compaq Presario x1208, x1208AP, x1209, x1209AP
Compaq Presario x1210, x1210AP, x1210CA, x1210US
Compaq Presario x1211, x1211AP, x1212, x1212AP
Compaq Presario x1213, x1213AP, x1214, x1214AP
Compaq Presario x1215, x1215AP, x1216, x1216AP
Compaq Presario x1217, x1217AP, x1218, x1218AP
Compaq Presario x1219, x1219AP
Compaq Presario x1220, x1220AP, x1220CA, x1220US
Compaq Presario x1221, x1221AP, x1222, x1222AP
Compaq Presario x1223, x1223AP, x1224, x1224AP

Compaq Presario x1225, x1225AP
Compaq Presario x1227, x1227AP, x1228, x1228AP
Compaq Presario x1229, x1229AP
Compaq Presario x1230, x1230AP, x1230US
Compaq Presario x1231, x1231AP, x1232, x1232AP
Compaq Presario x1233, x1233AP, x1234, x1234AP
Compaq Presario x1236, x1236AP, x1237, x1237AP
Compaq Presario x1238, x1238AP, x1239, x1239AP
Compaq Presario x1240, x1240AP, x1241, x1241AP
Compaq Presario x1242, x1242AP
Compaq Presario x1300 Series
Compaq Presario x1301, x1301AP, x1301US
Compaq Presario x1302, x1302AP, x1303, x1303AP
Compaq Presario x1304, x1304AP, x1305, x1305AP
Compaq Presario x1306, x1306AP, x1307, x1307AP
Compaq Presario x1308, x1308AP, x1309, x1309AP
Compaq Presario x1310, x1310AP, x1311, x1311AP
Compaq Presario x1312, x1312AP, x1313, x1313AP
Compaq Presario x1314, x1314AP, x1315, x1315AP
Compaq Presario x1316, x1316AP, x1317, x1317AP
Compaq Presario x1318, x1318AP, x1319, x1319AP
Compaq Presario x1320, x1320AP, x1321, x1321AP
Compaq Presario x1322, x1322AP, x1323, x1323AP
Compaq Presario x1324, x1324AP, x1325, x1325AP
Compaq Presario x1326, x1326AP, x1327, x1327AP
Compaq Presario x1328, x1328AP, x1329, x1329AP
Compaq Presario x1330, x1330AP
Compaq Presario x1360, x1360AP, x1360CL, x1360US
Compaq Presario x1370, x1370AP, x1370US
Compaq Presario x1390, x1390AP, x1390US
Compaq Presario x1390XX MV IUR
Compaq Presario x1397, x1397XX MV IUR
Compaq Presario x1400 Series
Compaq Presario x1402, x1402AP, x1403, x1403AP
Compaq Presario x1404, x1404AP, x1405, x1405AP
Compaq Presario x1406, x1406AP, x1407, x1407AP
Compaq Presario x1408, x1408AP, x1409, x1409AP
Compaq Presario x1410, x1410AP, x1411, x1411AP
Compaq Presario x1412, x1412AP, x1413, x1413AP
Compaq Presario x1414, x1414AP, x1415, x1415AP
Compaq Presario x1416, x1416AP, x1417, x1417AP
Compaq Presario x1418, x1418AP, x1419, x1419AP
Compaq Presario x1420, x1420AP, x1421, x1421AP
Compaq Presario x1422, x1422AP, x1423, x1423AP
Compaq Presario x1424, x1424AP, x1425, x1425AP
Compaq Presario x1426, x1426AP, x1427, x1427AP
Compaq Presario x1428, x1428AP, x1429, x1429AP

Compaq Presario x1430, x1430AP, x1431, x1431AP
Compaq Presario x1432, x1432AP, x1433, x1433AP
Compaq Presario x1434, x1434AP
Compaq Presario x1460, x1460CA, x1460US
Compaq Presario x1480, x1480US, x1480XX MV IUR
Hewlett Packard Business NoteBook NC4000 Series (60 watts)
Hewlett Packard Pavilion zt3000 Series (60 watts)
Hewlett Packard Pavilion zt3001, zt3007 Series (60 watts)
Hewlett Packard Pavilion zt3010, zt3011, zt3012 Series (60 watts)
Hewlett Packard Pavilion zt3013, zt3014, zt3015 Series (60 watts)
Hewlett Packard Pavilion zt3016, zt3017 Series (60 watts)
Hewlett Packard Pavilion zt3018, zt3019 Series (60 watts)
Hewlett Packard Pavilion zt3020, zt3021, zt3022 Series (60 watts)
Hewlett Packard Pavilion zt3023, zt3024, zt3025 Series (60 watts)
Hewlett Packard Pavilion zt3026, zt3027 Series (60 watts)
Hewlett Packard Pavilion zt3028, zt3029 Series (60 watts)
Hewlett Packard Pavilion zt3030, zt3031, zt3032 Series (60 watts)
Hewlett Packard Pavilion zt3033, zt3034, zt3035 Series (60 watts)
Hewlett Packard Pavilion zt3036, zt3037 Series (60 watts)
Hewlett Packard Pavilion zt3038, zt3039 Series (60 watts)
Hewlett Packard Pavilion zt3040, zt3041, zt3042 Series (60 watts)
Hewlett Packard Pavilion zt3043, zt3044, zt3045 Series (60 watts)
Hewlett Packard Pavilion zt3046, zt3047 Series (60 watts)
Hewlett Packard Pavilion zt3048, zt3049 Series (60 watts)
Hewlett Packard Pavilion zt3050, zt3051 Series (60 watts)
Hewlett Packard Pavilion zt3057 Series (60 watts)
Hewlett Packard Pavilion zt3068 Series (60 watts)
Hewlett Packard Pavilion zt3100 Series (60 watts)
Hewlett Packard Pavilion zt3101, zt3105 Series (60 watts)
Hewlett Packard Pavilion zt3106 Series (60 watts)
Hewlett Packard Pavilion zt3110, zt3111 Series (60 watts)
Hewlett Packard Pavilion zt3113, zt3114 Series (60 watts)
Hewlett Packard Pavilion zt3115, zt3116 Series (60 watts)
Hewlett Packard Pavilion zt3120 Series (60 watts)
Hewlett Packard Pavilion zt3130, zt3131 Series (60 watts)
Hewlett Packard Pavilion zt3140 Series (60 watts)
Hewlett Packard Pavilion zt3170 Series (60 watts)
Hewlett Packard Pavilion zt3200 Series (60 watts)
Hewlett Packard Pavilion zt3201, zt3202, zt3203 Series (60 watts)
Hewlett Packard Pavilion zt3204, zt3205, zt3206 Series (60 watts)
Hewlett Packard Pavilion zt3206, zt3207 Series (60 watts)
Hewlett Packard Pavilion zt3208, zt3209 Series (60 watts)
Hewlett Packard Pavilion zt3210, zt3211 Series (60 watts)
Hewlett Packard Pavilion zt3212, zt3213 Series (60 watts)
Hewlett Packard Pavilion zt3214, zt3215, zt3216 Series (60 watts)
Hewlett Packard Pavilion zt3217, zt3218, zt3219 Series (60 watts)
Hewlett Packard Pavilion zt3220, zt3221, zt3222 Series (60 watts)

Hewlett Packard Pavilion zt3223, zt3224, zt3225 Series (60 watts)
Hewlett Packard Pavilion zt3228, zt3229 Series (60 watts)
Hewlett Packard Pavilion zt3230, zt3231, zt3232 Series (60 watts)
Hewlett Packard Pavilion zt3235, zt3236, zt3237 Series (60 watts)
Hewlett Packard Pavilion zt3238, zt3239 Series (60 watts)
Hewlett Packard Pavilion zt3240, zt3241, zt3242 Series (60 watts)
Hewlett Packard Pavilion zt3250 Series (60 watts)
Hewlett Packard Pavilion zt3260 Series (60 watts)
Hewlett Packard Pavilion zt3280 Series (60 watts)
Hewlett Packard Pavilion zt3300 Series (60 watts)
Hewlett Packard Pavilion zt3300, zt3301, zt3302 Series (60 watts)
Hewlett Packard Pavilion zt3303, zt3304, zt3305 Series (60 watts)
Hewlett Packard Pavilion zt3306, zt3307 Series (60 watts)
Hewlett Packard Pavilion zt3308, zt3309 Series (60 watts)
Hewlett Packard Pavilion zt3310, zt3311, zt3312 Series (60 watts)
Hewlett Packard Pavilion zt3313, zt3314, zt3315 Series (60 watts)
Hewlett Packard Pavilion zt3316, zt3317 Series (60 watts)
Hewlett Packard Pavilion zt3318, zt3319 Series (60 watts)
Hewlett Packard Pavilion zt3320, zt3321, zt3322 Series (60 watts)
Hewlett Packard Pavilion zt3323, zt3324, zt3325 Series (60 watts)
Hewlett Packard Pavilion zt3326, zt3327 Series (60 watts)
Hewlett Packard Pavilion zt3328, zt3329 Series (60 watts)
Hewlett Packard Pavilion zt3330, zt3331, zt3332 Series (60 watts)
Hewlett Packard Pavilion zt3333, zt3334, zt3335 Series (60 watts)
Hewlett Packard Pavilion zt3336, zt3337 Series (60 watts)
Hewlett Packard Pavilion zt3338, zt3339 Series (60 watts)
Hewlett Packard Pavilion zt3340, zt3341, zt3342 Series (60 watts)
Hewlett Packard Pavilion zt3343, zt3344, zt3345 Series (60 watts)
Hewlett Packard Pavilion zt3346, zt3349 Series (60 watts)
Hewlett Packard Pavilion zt3350, zt3351 Series (60 watts)
Hewlett Packard Pavilion zt3368, zt3370 Series (60 watts)
Hewlett Packard Pavilion zt3377 Series (60 watts)
Hewlett Packard Pavilion zt3380 Series (60 watts)
Hewlett Packard Tablet PC TC1000 Series (60 watts)
Hewlett Packard Tablet PC TC1100 Series (60 watts)

AC1914

Voltagem: 19 volts

Amperagem: 3,42 ampères

Potência: 64,98 watts

Modelos de notebooks compatíveis com este código (179 modelos disponíveis)

Acer Aspire 1410 Series

Acer Aspire 1411, 1411WLMi

Acer Aspire 1412, 1412LC, 1412LCi
Acer Aspire 1412LM, 1412LMi
Acer Aspire 1412WLMi
Acer Aspire 1413, 1413LC
Acer Aspire 1413LM, 1413LMi
Acer Aspire 1413WLMi
Acer Aspire 1414, 1414L, 1414LC
Acer Aspire 1414LM, 1414LMi
Acer Aspire 1414WLCi, 1414WLMi
Acer Aspire 1681, 1681LC, 1681LCi
Acer Aspire 1681LMi, 1681WLC, 1681WLCi
Acer Aspire 1681WLM, 1681WLMi
Acer Aspire 1682, 1682LCi, 1682LMi
Acer Aspire 1682WLC, 1682WLCi
Acer Aspire 1682WLM, 1682WLMi
Acer Aspire 1683, 1683LMi
Acer Aspire 1683WLM, 1683WLMi
Acer Aspire 1684, 1684WLMi
Acer Aspire 1685, 1685WLCi, 1685WLMi
Acer Aspire 2000 Series
Acer Aspire 2000, 2000LCi, 2000LMi
Acer Aspire 2000WLCi, 2000WLMi
Acer Aspire 2001, 2001LC, 2001LCe
Acer Aspire 2001LCi, 2001LMi
Acer Aspire 2001WLCi, 2001WLMi
Acer Aspire 2002, 2002LCi, 2002LMi
Acer Aspire 2002WLCi, 2002WLMi
Acer Aspire 2003, 2003LC, 2003LCi
Acer Aspire 2003LM, 2003LMi
Acer Aspire 2003WLCi, 2003WLMi
Acer Aspire 2010 Series
Acer Aspire 2010, 2010LMi
Acer Aspire 2010WLCi, 2010WLMi
Acer Aspire 2012, 2012LC, 2012LCi
Acer Aspire 2012LCi, 2012LMi
Acer Aspire 2012WLCi, 2012WLMi
Acer Aspire 2013, 2013WLMi
Acer Aspire 2014, 2014WLMi
Acer Aspire 2016, 2016WLMi
Acer Aspire 2020 Series
Acer Aspire 2020, 2020LC, 2020WLCi
Acer Aspire 2021, 2021WLMi
Acer Aspire 2023, 2023LMi
Acer Aspire 2023WLCi, 2023WLMi
Acer Aspire 2024, 2024WLCi, 2024WLMi
Acer Aspire 2025, 2025LMi
Acer Aspire 2025WLCi, 2025WLMi

Acer Aspire 2026, 2026LMi, 2026WLMi
Acer TravelMate Série 2300
Acer TravelMate 2300, 2300LC, 2300LCi
Acer TravelMate 2300LM
Acer TravelMate 2301, 2301LC, 2301LCi
Acer TravelMate 2301LM, 2301LMi
Acer TravelMate 2301NLC, 2301NLCi, 2301NXCi
Acer TravelMate 2301WLC, 2301WLCi
Acer TravelMate 2301WLM, 2301WLMi
Acer TravelMate 2301XC, 2301XCi
Acer TravelMate 2302, 2302LC, 2302LCi
Acer TravelMate 2302LM, 2302LMi, 2302NLCi
Acer TravelMate 2302WLM, 2302WLMi
Acer TravelMate 2303, 2303LC, 2303LCi
Acer TravelMate 2303LM, 2303LMi
Acer TravelMate 2303NLC, 2303NLCi
Acer TravelMate 2303WLCi, 2303WLM, 2303WLMi
Acer TravelMate 2303XC
Acer TravelMate 2350
Acer TravelMate 2352, 2352LCi
Acer TravelMate 2353, 2353LC, 2352LCi
Acer TravelMate 2353LM, 2353LMi
Acer TravelMate 2353WLMi
Acer TravelMate 3200 Series
Acer TravelMate 3200, 3200XCi, 3200XMi
Acer TravelMate 3201, 3201XCi, 3201XMi
Acer TravelMate 3201NXCi
Acer TravelMate 3202, 3202XCi, 3202XMi
Acer TravelMate 3203, 3203XCi, 3203XMi
Acer TravelMate 3205, 3205XMi
Acer TravelMate 370, 370TCi, 370Ti, 370TMi (65 watts)
Acer TravelMate 372, 372LCi, 372LMi (65 watts)
Acer TravelMate 372TC, 372TCi (65 watts)
Acer TravelMate 372Ti, 372TM, 372TMi (65 watts)
Acer TravelMate 374, 374TCi (65 watts)
Acer TravelMate 380 Series (65 watts)
Acer TravelMate 380, 380LCi, 372LMi (65 watts)
Acer TravelMate 380TCi (65 watts)
Acer TravelMate 381, 381TC, 381TCi (65 watts)
Acer TravelMate 381Ti (65 watts)
Acer TravelMate 382, 382LCi (65 watts)
Acer TravelMate 382TC, 382TCi, 382Ti (65 watts)
Acer TravelMate 382TM, 382TMi (65 watts)
Acer TravelMate 383, 383TCi (65 watts)
Acer TravelMate 4000 Series
Acer TravelMate 4000, 4000LCi, 4000LMi
Acer TravelMate 4000NLCi, 4000WLCi, 4000WLMi

Acer TravelMate 4001, 4001LC, 4001LCi
Acer TravelMate 4001LM, 4001LMi, 4001NLCi
Acer TravelMate 4001WLC, 4001WLCi
Acer TravelMate 4001WLM, 4001WLMi
Acer TravelMate 4001XCi
Acer TravelMate 4002, 4002LC, 4002LCi
Acer TravelMate 4002LM, 4002LMi, 4002NLCi
Acer TravelMate 4002WLCi, 4002WLM, 4002WLMi
Acer TravelMate 4050 Series (65 watts)
Acer TravelMate 4050, 4050LC, 4050LCi (65 watts)
Acer TravelMate 4050LM, 4050LMi (65 watts)
Acer TravelMate 4052, 4052LCi (65 watts)
Acer TravelMate 4052LMi, 4052NLCi (65 watts)
Acer TravelMate 4052WLCi, 4052WLMi (65 watts)
Acer TravelMate 4053, 4053LMi (65 watts)
Acer TravelMate 4500 Series
Acer TravelMate 4500, 4500LCi, 4500LMi
Acer TravelMate 4500WLCi, 4500WLMi
Acer TravelMate 4501, 4501LC, 4501LCi
Acer TravelMate 4501LMi, 4501WLC, 4501WLCi
Acer TravelMate 4501WLM, 4501WLMi
Acer TravelMate 4502, 4502LC, 4502LCi
Acer TravelMate 4502LMi, 4502WLCi
Acer TravelMate 4502WLM, 4502WLMi
Acer TravelMate 4503, 4503LCi
Acer TravelMate 4503WLCi, 4503LMi
Acer TravelMate 4504, 4504LM, 4504LMi
Acer TravelMate 530 Series
Acer TravelMate 530LC, 530LCi
Acer TravelMate 530XC, 530XCi
Acer TravelMate 531LC, 531LCi
Acer TravelMate 531XC, 531XCi
Acer TravelMate 531XV, 531XVi
Acer TravelMate 530XV, 530XVi
Acer TravelMate 533LC, 533LCi
Acer TravelMate 533XC, 533XCi
Acer TravelMate 533XV, 533XVi
Acer TravelMate 534LC, 534LCi, 534TL
Acer TravelMate 534XC, 534XCi, 534XV
Acer TravelMate 535LC, 535LCi
Acer TravelMate 536LCi
Acer TravelMate 650 Series
Acer TravelMate 650LC, 650XC, 650XCi
Acer TravelMate 653LC, 653LCi
Acer TravelMate 653XC, 653XCi, 653XV
Acer TravelMate 654LC, 654LCi
Acer TravelMate 654XC, 654XCi, 654XV

Acer TravelMate 655LCi
Acer TravelMate 660 Series
Acer TravelMate 660LCi, 660LMi
Acer TravelMate 661LC, 661LCi
Acer TravelMate 661LM, 661LMi
Acer TravelMate 661XC, 661XCi, 661XVi
Acer TravelMate 662LC, 662LCi
Acer TravelMate 662LM, 662LMi, 662XCi
Acer TravelMate 663LCi, 663LM, 663LMi
Acer TravelMate 800 Series
Acer TravelMate 800, 800LC, 800LCi
Acer TravelMate 800LC, 800LCi, 800LCib
Acer TravelMate 800LM, 800LMi
Acer TravelMate 800LMi, 800LMib
Acer TravelMate 800XC, 800XCi
Acer TravelMate 801LC, 801LCi, 801LCib
Acer TravelMate 801LMi, 801LMib
Acer TravelMate 801XC, 801XCi, 801XVi
Acer TravelMate 802LCi, 802LCiB
Acer TravelMate 802LMi, 802LMib, 802XCi
Acer TravelMate 803LC, 803LCi, 803LCib
Acer TravelMate 803LM, 803LMi, 803LMib
Acer TravelMate 803XCi, 803XVi
Acer TravelMate 804LC, 804LCi, 804LCib
Acer TravelMate 804LM, 804LMi, 804LMib
Gateway 2000 M305CRV Series
Gateway 2000 M320 Series
Gateway 2000 M4520GZ Series
Gateway 2000 M4525GZ Series
Gateway 2000 M500 Series
Gateway 2000 M505 Series
Gateway 2000 Solo M500 Series
Gateway 2000 Solo M505 Series
Lifetec LT6179
Medion MD6179
Medion WIM2000

AC1514

Voltagem: 19 volts

Amperagem: 3,1 ampères

Potência: 58,9 watts

Modelos de notebooks compatíveis com este código (166 modelos disponíveis)

Acer Alpha 550

Acer Aspire Série 1200
Acer Extensa Séries 700, 700T
Acer TravelMate 200, 200DX, 200T, 201, 201T, 202, 202T
Acer Extensa Séries 710, 711, 712, 710DX, 710T, 710TE, 711TE, 712TE
Acer TravelMate 210, 210, 210T, 210TER, 210TXF, 211, 211T, 212, 212T, 212TE, 212TXV, 213, 213T, 213TX, 213TXV
Acer TravelMate 220, 222, 223, 225, 222X, 223X, 223XC, 223XV, 225X, 225XC, 225XV
Acer TravelMate 260, 261, 261X, 261XC, 261XV
Acer TravelMate 270, 272, 273, 275, 270XV, 272LC, 272X, 272XV, 272XVi, 273X, 273XV, 275LC
Acer TravelMate 350, 351, 352, 353, 354, 350TE, 350TE-N, 351TE, 351TEV, 354TE, 354TEV
Acer TravelMate 360, 361, 364, 361EVi, 364ECi
Acer TravelMate 512DX, 512T, 512TE, 512T-64, 513DX, 513T, 514T, 514TXV, 515TE, 516TE, 517TE
Acer TravelMate Série 550
Acer TravelMate 600, 602, 603, 604, 600TER, 602TER, 603TER, 604TER
Acer TravelMate 610, 611, 612, 613, 614, 610TXC, 610TXV, 610TXVi, 611TXC, 611TXCi, 611TXV, 612TXC, 612TXCi, 612TXV, 613TXC, 613TXV, 614TXVCi
Acer TravelMate 620, 621, 623, 621LV, 621XC, 621XV, 623LC, 623LCi
Acer TravelMate 630, 632, 633, 630XV, 630XCi, 632XCi, 633LCi
Acer TravelMate 720, 722, 723, 720TX, 720TXV, 721TX, 722iTX, 722iTXV, 722TX, 723TX, 723TXV
Acer TravelMate 730, 732, 734, 735, 730TX, 730TXV, 732TLV, 732TX, 732TXV, 734TL, 734TXV, 735TLV, 736, 737, 738, 739, 736TL, 736TLV, 737TLV, 738TLV, 739GTLV, 739TLV
Acer TravelMate 740, 741, 744, 740LVF, 741LVF, 744LCF
Acer TravelMate K-550
Acer TravelMate 520, 521, 524, 520iT, 521TE, 521TEV, 521TXV, 524TE, 524TXV, 525, 527, 529, 525TE, 525TX, 525TXV, 527TXV, 528TE, 529ATXV, 529TX, 529TXV
Acer Alpha 550LC, 550LV, 550XV
Acer Alpha 551, 551VX
Acer Aspire 1200X, 1200XV
Acer Aspire 1202, 1202X
Acer Aspire 1203X, 1203XC, 1203XV
Acer TravelMate 230, 233, 234, 230XC, 230XV, 230XV-PRO
Acer TravelMate 233LC, 233X, 233XV, 233XVi, 234LCi
Acer TravelMate 270XV
Acer TravelMate 272LC, 272X, 272XV, 272XVi
Acer TravelMate 273X, 273XV, 275LC
Acer TravelMate 280, 281, 283 Series
Acer TravelMate 281XC, 281XV
Acer TravelMate 283LC, 283LCi
Acer TravelMate 283XV, 283XVi
Acer TravelMate 290 Series
Acer TravelMate 290LC, 290LCi, 290LMi
Acer TravelMate 290XCi, 290Xi

Acer TravelMate 290XMi, 290X
Acer TravelMate 291LCi, 291LCi-G
Acer TravelMate 291LMi, 291LMi-G
Acer TravelMate 291XCi, 291XCiH
Acer TravelMate 292LC, 292LCi, 292LM, 292LMi
Acer TravelMate 293LCi, 293LMi
Acer TravelMate 340, 341, 342, 343 Series
Acer TravelMate 340T, 341TV, 342T, 343TV
Acer TravelMate 345, 347 Series
Acer TravelMate 345T, 347T Series
Acer TravelMate 350, 351, 352, 353, 354 Series
Acer TravelMate 350TE, 350TE-N, 351TE, 351TEV
Acer TravelMate 352TE, 353TE, 353TEV
Acer TravelMate 354TE, 354TEV
Acer TravelMate 360, 361, 364 Series
Acer TravelMate 361EVi, 364ECi Series
Acer TravelMate 370 Series
Acer TravelMate 370, 370TCi, 370Ti, 370TMi
Acer TravelMate 371LCi, 371LMi
Acer TravelMate 371TCi, 371TCi XP
Acer TravelMate 371Ti, 371TMi
Acer TravelMate 372, 372LCi, 372LMi
Acer TravelMate 372TC, 372TCi
Acer TravelMate 372Ti, 372TM, 372TMi
Acer TravelMate 374, 374TCi
Acer TravelMate 380 Series
Acer TravelMate 380, 380LCi, 372LMi
Acer TravelMate 380TCi
Acer TravelMate 381, 381TC, 381TCi
Acer TravelMate 381Ti
Acer TravelMate 382, 382LCi
Acer TravelMate 382TC, 382TCi, 382Ti
Acer TravelMate 382TM, 382TMi
Acer TravelMate 383, 383TCi
Acer TravelMate 4050 Series
Acer TravelMate 4050, 4050LC, 4050LCi
Acer TravelMate 4050LM, 4050LMi
Acer TravelMate 4052, 4052LCi
Acer TravelMate 4052LMi, 4052NLCi
Acer TravelMate 4052WLCi, 4052WLMi
Acer TravelMate 4053, 4053LMi
Acer TravelMate 510, 512, 513, 514, 515, 516, 517 Series
Acer TravelMate 512DX, 512T, 512TE, 512T-64
Acer TravelMate 513DX, 513T, 514T, 514TXV
Acer TravelMate 515TE, 516TE, 517TE
Acer TravelMate 520, 521, 524 Series
Acer TravelMate 520iT, 521TE, 521TEV, 521TXV

Acer TravelMate 524TE, 524TXV
Acer TravelMate 525, 527, 529 Series
Acer TravelMate 525TE, 525TX, 525TXV
Acer TravelMate 527TXV, 528TE
Acer TravelMate 529ATXV, 529TX, 529TXV
Acer TravelMate 550 Series
Acer TravelMate 550LC, 550LV, 550XV
Acer TravelMate 551, 551XV
Acer TravelMate 600, 602, 603, 604 Series
Acer TravelMate 6000 Series
Acer TravelMate 6000, 6000LCi
Acer TravelMate 6001
Acer TravelMate 6002, 6002LCi
Acer TravelMate 6003LC, 6003LCi
Acer TravelMate 6003LM, 6003LMi
Acer TravelMate 6004, 6004LC, 6004LCi
Acer TravelMate 6004LMi
Acer TravelMate 600TER, 602TER, 603TER, 604TER
Acer TravelMate 610, 611, 612, 613, 614 Series
Acer TravelMate 610TXC, 610TXV, 610TXVi
Acer TravelMate 611TXC, 611TXCi, 611TXV
Acer TravelMate 612TXC, 612TXCi, 612TXV
Acer TravelMate 613TXC, 613TXV, 614TXVCi
Acer TravelMate 620, 621, 623 Series
Acer TravelMate 621LV, 621XC, 621XV
Acer TravelMate 623LC, 623LCi
Acer TravelMate 630, 632, 633 Series
Acer TravelMate 630XV, 630XCi
Acer TravelMate 632XCi, 633LCi Series
Acer TravelMate 720, 722, 723 Series
Acer TravelMate 720TX, 720TXV, 721TX
Acer TravelMate 722iTX, 722iTXV, 722TX
Acer TravelMate 723TX, 723TXV
Acer TravelMate 730, 732, 734, 735 Series
Acer TravelMate 730TX, 730TXV
Acer TravelMate 732TLV, 732TX, 732TXV
Acer TravelMate 734TL, 734TXV
Acer TravelMate 735TLV
Acer TravelMate 736, 737, 738, 739 Series
Acer TravelMate 736TL, 736TLV
Acer TravelMate 737TLV, 738TLV
Acer TravelMate 739GTLV, 739TLV
Acer TravelMate 740, 741, 744 Series
Acer TravelMate 740LVF, 741LVF, 744LCF
Acer TravelMate 8000 Series
Acer TravelMate 8000, 8000LCi, 8000LMi
Acer TravelMate 8001, 8001LCib

Acer TravelMate 8002, 8002LC
Acer TravelMate 8002LCi, 8002LCib, 8002LMi
Acer TravelMate 8003, 8003LC
Acer TravelMate 8003LCi, 8003LCib
Acer TravelMate 8003LM, 8003LMi, 8003LMib
Acer TravelMate 8004, 8004LCi, 8004LCib
Acer TravelMate 8004LM, 8004LMi, 8004LMib
Acer TravelMate 8005, 8005LCi, 8005LCib
Acer TravelMate 8005LMi, 8005LMib
Acer TravelMate 8006, 8006LCi
Acer TravelMate 8006LM, 8006LMi, 8006LMib
Acer TravelMate a550 Series
Acer TravelMate a550LC, a550LV, a550XV
Acer TravelMate a551, a551XV
Acer TravelMate Alpha 550 Series
Acer TravelMate Alpha 550LC, 550LV, 550XV
Acer TravelMate Alpha 551, 551XV
Acer TravelMate C300 Series
Acer TravelMate C300XCi, C300XCi-G
Acer TravelMate C301XCi, C301XCi-G
Acer TravelMate C302MXi
Acer TravelMate C302XMi, C302XMi-G
Acer TravelMate K-550 Series
Aopen 1535
Hitachi Flora 200
Hitachi Flora 20NV
Hitachi Flora 270GX NW1
Hitachi Flora 270GX NW2
Hitachi Flora 270GX NW3
Hitachi Flora 270HX NW6, 270HX NW7
Hitachi Flora 270W NW6
Hitachi Prius Note 20U
Hyperdata CN69

HP1512

Voltagem: 19 volts

Amperagem: 3,68 ampères

Potência: 69,92 watts

Modelos de notebooks compatíveis com este código (325 modelos disponíveis)

Compaq Business Notebook NX9020 Series

Compaq Business Notebook NX9030 Series

Hewlett Packard OmniBook Série 2100

Hewlett Packard OmniBook 2100, 2103, 2105

Hewlett Packard OmniBook 3000, 3000CTX
Hewlett Packard OmniBook Série 3100
Hewlett Packard OmniBook 3100, 3101
Hewlett Packard OmniBook Série 4100
Hewlett Packard OmniBook Série 4150
Hewlett Packard OmniBook Série 500
Hewlett Packard OmniBook Série 500B
Hewlett Packard OmniBook Série 510
Hewlett Packard OmniBook Série 6000
Hewlett Packard OmniBook Série 6050
Hewlett Packard OmniBook Série 6100
Hewlett Packard OmniBook Séries 7100, 7130, 7150
Hewlett Packard OmniBook Série 900
Hewlett Packard OmniBook Série vt6200
Hewlett Packard OmniBook Série XE
Hewlett Packard OmniBook Série XE2
Hewlett Packard OmniBook Série XE3
Hewlett Packard OmniBook Série XE3L
Hewlett Packard OmniBook Série xe4100 (Fonte de 60 watts)
Hewlett Packard OmniBook Série xe4400 (Fonte de 60 watts)
Hewlett Packard OmniBook Série xe4400s (Fonte de 60 watts)
Hewlett Packard OmniBook Série xe4500 (Fonte de 60 watts)
Hewlett Packard OmniBook Série xt100
Hewlett Packard OmniBook Série xt1000
Hewlett Packard OmniBook Série xt1500
Hewlett Packard OmniBook Série xt6050
Hewlett Packard OmniBook Série xt6200
Hewlett Packard Pavilion n3000 Series
Hewlett Packard Pavilion n3100, n3110, n3150 Series
Hewlett Packard Pavilion n3190 Series
Hewlett Packard Pavilion n3200, n3210, n3215, n3250 Series
Hewlett Packard Pavilion n3270, n3290, n3295 Series
Hewlett Packard Pavilion n3300, n3310, n3330 Series
Hewlett Packard Pavilion n3350, n3370, n3390 Series
Hewlett Packard Pavilion n3400, n3402, n3410 Series
Hewlett Packard Pavilion n3438, n3478, n3490 Series
Hewlett Packard Pavilion n5000 Series
Hewlett Packard Pavilion n5125, n5130, n5135, n5140 Series
Hewlett Packard Pavilion n5150, n5170, n5190, n5195 Series
Hewlett Packard Pavilion n5210, n5221, n5240, n5241 Series
Hewlett Packard Pavilion n5250, n5261, n5270, n5271 Series
Hewlett Packard Pavilion n5290, n5295 Series
Hewlett Packard Pavilion n5310, n5311 Series
Hewlett Packard Pavilion n5340, n5341, n5350, n5351 Series
Hewlett Packard Pavilion n5371, n5381, n5390 Series
Hewlett Packard Pavilion n5402, n5415, n5420, n5421 Series
Hewlett Packard Pavilion n5422, n5425, n5430, n5435 Series

Hewlett Packard Pavilion n5440, n5441, n5442, n5444 Series
Hewlett Packard Pavilion n5445, n5450, n5452, n5454 Series
Hewlett Packard Pavilion n5455, n5461, n5462 Series
Hewlett Packard Pavilion n5470, n5472, n5474, n5475 Series
Hewlett Packard Pavilion n5490, n5491, n5495 Series
Hewlett Packard Pavilion n6000 Series
Hewlett Packard Pavilion n6190, n6195 Series
Hewlett Packard Pavilion n6395, n6396 Series
Hewlett Packard Pavilion n6397, n6398, n6399 Series
Hewlett Packard Pavilion n6400, n6401, n6402 Series
Hewlett Packard Pavilion n6403, n6404 Series
Hewlett Packard Pavilion n6490 Series
Hewlett Packard Pavilion xf100 Series
Hewlett Packard Pavilion xf125, xf145 Series
Hewlett Packard Pavilion xf235, xf255
Hewlett Packard Pavilion xf300 Series
Hewlett Packard Pavilion xf315 Series
Hewlett Packard Pavilion xf325, xf328 Series
Hewlett Packard Pavilion xh136, xh156, xh176 Series
Hewlett Packard Pavilion xh215, xh216, xh226 Series
Hewlett Packard Pavilion xh335, xh355, xh365, xh395 Series
Hewlett Packard Pavilion xh455, xh485 Series
Hewlett Packard Pavilion xh535, xh545, xh555, xh575 Series
Hewlett Packard Pavilion xh635, xh675
Hewlett Packard Pavilion xt118 Series
Hewlett Packard Pavilion xt155 Series
Hewlett Packard Pavilion xt236, xt276 Series
Hewlett Packard Pavilion xt375 Series
Hewlett Packard Pavilion xt412 Series
Hewlett Packard Pavilion xt545 Series
Hewlett Packard Pavilion xt595 Series
Hewlett Packard Pavilion xu155 Series
Hewlett Packard Pavilion xz133, xz148 Series
Hewlett Packard Pavilion xz163, xz168 Series
Hewlett Packard Pavilion xz185, xz275, xz295 Series
Hewlett Packard Pavilion xz335, xz355 Series
Hewlett Packard Pavilion ze1110, ze1115 Series
Hewlett Packard Pavilion ze1145 Series
Hewlett Packard Pavilion ze1201, ze1202
Hewlett Packard Pavilion ze1210, ze1230
Hewlett Packard Pavilion ze1250, ze1260
Hewlett Packard Pavilion ze4101, ze4102 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4103, ze4105 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4111, ze4115 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4120, ze4123 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4125 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4130, ze4133 (Fonte de 60 watts)

Hewlett Packard Pavilion ze4140, ze4145 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4200, ze4201, ze4202 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4204, ze4206 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4207, ze4208, ze4209 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4210, ze4211 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4217, ze4218, ze4218 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4220, ze4221, ze4222 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4224, ze4228, ze4229 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4230, ze4231, ze4232 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4234, ze4236, ze4239 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4240, ze4241 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4261, ze4262, ze4268 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4271, ze4274, ze4278 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4281, ze4282 (Fonte de 60 watts)
Hewlett Packard Pavilion ze4292, ze4294, ze4298 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5000 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5155, ze5170 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5185, ze5190 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5200, ze5207 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5217 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5228 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5232, ze5238 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5240, ze5242, ze5244 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5250, ze5252, ze5258 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5262 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5270, ze5279 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5300 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5370, ze5375 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5830, ze5385 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5390, ze5395 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5400, ze5407 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5470, ze5475, ze5478 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5490 (Fonte de 60 watts)
Hewlett Packard Pavilion zt1000 Series
Hewlett Packard Pavilion zt1114 Series
Hewlett Packard Pavilion zt1120, zt1121, zt1125 Series
Hewlett Packard Pavilion zt1130, zt1131 Series
Hewlett Packard Pavilion zt1132, zt1135 Series
Hewlett Packard Pavilion zt1141, zt1142, zt1145 Series
Hewlett Packard Pavilion zt1150, zt1151 Series
Hewlett Packard Pavilion zt1152, zt1155 Series
Hewlett Packard Pavilion zt1161, zt1162 Series
Hewlett Packard Pavilion zt1170, zt1171 Series
Hewlett Packard Pavilion zt1172, zt1175 Series
Hewlett Packard Pavilion zt1180, zt1182, zt1185 Series
Hewlett Packard Pavilion zt1190, zt1192, zt1195 Series
Hewlett Packard Pavilion zt1201 Series

Hewlett Packard Pavilion zt1210, zt1211, zt1213 Series
Hewlett Packard Pavilion zt1230, zt1231, zt1233, zt1235 Series
Hewlett Packard Pavilion zt1243 Series
Hewlett Packard Pavilion zt1250 Series
Hewlett Packard Pavilion zt1260, zt1261 (Fonte de 60 watts)
Hewlett Packard Pavilion zt1270, zt1271 (Fonte de 60 watts)
Hewlett Packard Pavilion zt1290 (Fonte de 60 watts)
Hewlett Packard Pavilion zu1155, zu1175 (Fonte de 60 watts)
Hewlett Packard Pavilion ze5500, ze5501, ze5504 Series (70 watts)
Hewlett Packard Business NoteBook N1050v Series (70 watts)
Hewlett Packard Business NoteBook NC4010 Series (70 watts)
Hewlett Packard Business NoteBook NC6000 Series (70 watts)
Hewlett Packard Business NoteBook NC8000 Series (70 watts)
Hewlett Packard Business NoteBook NW8000 Series (70 watts)
Hewlett Packard Business NoteBook NX5000 Series (70 watts)
Hewlett Packard Business NoteBook NX7000 Series (70 watts)
Hewlett Packard Business NoteBook NX7010 Series (70 watts)
Hewlett Packard Business NoteBook NX9000 Series (70 watts)
Hewlett Packard Business NoteBook NX9005 Series (70 watts)
Hewlett Packard Business NoteBook NX9008 Series (70 watts)
Hewlett Packard Business NoteBook NX9010 Series (70 watts)
Hewlett Packard Business NoteBook NX9020 Series (70 watts)
Hewlett Packard Business Notebook NX9030 Series (70 watts)
Hewlett Packard Pavilion n5481, n5482, n5484, n5485 Series
Hewlett Packard Pavilion xf335 Series
Hewlett Packard Pavilion xt115 Series (70 watts)
Hewlett Packard Pavilion xt125, xt128 Series (70 watts)
Hewlett Packard Pavilion xt178 Series (70 watts)
Hewlett Packard Pavilion xt183, xt188 Series (70 watts)
Hewlett Packard Pavilion xt345 Series (70 watts)
Hewlett Packard Pavilion xt395 Series (70 watts)
Hewlett Packard Pavilion xt4316, xt4316wm Series (70 watts)
Hewlett Packard Pavilion xt4328, xt4328cl Series (70 watts)
Hewlett Packard Pavilion xt4345, xt4345qv Series (70 watts)
Hewlett Packard Pavilion xt512 Series (70 watts)
Hewlett Packard Pavilion xt5335, xt5335qv Series (70 watts)
Hewlett Packard Pavilion xt5366, xt5366wm Series (70 watts)
Hewlett Packard Pavilion xt5377, xt5377qv Series (70 watts)
Hewlett Packard Pavilion xt555, xt565, xt575 Series (70 watts)
Hewlett Packard Pavilion xt585, xt595 Series (70 watts)
Hewlett Packard Pavilion ze4212, ze4214 Series (70 watts)
Hewlett Packard Pavilion ze4250, ze4251 Series (70 watts)
Hewlett Packard Pavilion ze4257, ze4258 Series (70 watts)
Hewlett Packard Pavilion ze4284, ze4288 Series (70 watts)
Hewlett Packard Pavilion ze4292, ze4294, ze4298 Series (70 watts)
Hewlett Packard Pavilion ze4300, ze4301, ze4302 Series (70 watts)
Hewlett Packard Pavilion ze4305, ze4306, ze4307 Series (70 watts)

Hewlett Packard Pavilion ze4308 Series (70 watts)
Hewlett Packard Pavilion ze4310, ze4311, ze4312 Series (70 watts)
Hewlett Packard Pavilion ze4313, ze4314, ze4315 Series (70 watts)
Hewlett Packard Pavilion ze4316, ze4317, ze4318, ze4319 Series (70 watts)
Hewlett Packard Pavilion ze4320, ze4321, ze4322 Series (70 watts)
Hewlett Packard Pavilion ze4323, ze4325 Series (70 watts)
Hewlett Packard Pavilion ze4326, ze4328 Series (70 watts)
Hewlett Packard Pavilion ze4330, ze4332, ze4333 Series (70 watts)
Hewlett Packard Pavilion ze4334, ze4335, ze4336 Series (70 watts)
Hewlett Packard Pavilion ze4345, ze4347 Series (70 watts)
Hewlett Packard Pavilion ze4348, ze4349 Series (70 watts)
Hewlett Packard Pavilion ze4350, ze4351, ze4352 Series (70 watts)
Hewlett Packard Pavilion ze4353, ze4354 Series (70 watts)
Hewlett Packard Pavilion ze4355, ze4356 Series (70 watts)
Hewlett Packard Pavilion ze4357, ze4358 Series (70 watts)
Hewlett Packard Pavilion ze4360 Series (70 watts)
Hewlett Packard Pavilion ze4365, ze4367 Series (70 watts)
Hewlett Packard Pavilion ze4370 Series (70 watts)
Hewlett Packard Pavilion ze4375 Series (70 watts)
Hewlett Packard Pavilion ze4380 Series (70 watts)
Hewlett Packard Pavilion ze4384, ze4385, ze4385 Series (70 watts)
Hewlett Packard Pavilion ze4400, ze4401, ze4402 Series (70 watts)
Hewlett Packard Pavilion ze4403, ze4404, ze4405 Series (70 watts)
Hewlett Packard Pavilion ze4407, ze4408, ze4409 Series (70 watts)
Hewlett Packard Pavilion ze4410, ze4411, ze4412 Series (70 watts)
Hewlett Packard Pavilion ze4413, ze4414, ze4415 Series (70 watts)
Hewlett Packard Pavilion ze4416, ze4417 Series (70 watts)
Hewlett Packard Pavilion ze4420, ze4423 Series (70 watts)
Hewlett Packard Pavilion ze4424, ze4425 Series (70 watts)
Hewlett Packard Pavilion ze4427, ze4428 Series (70 watts)
Hewlett Packard Pavilion ze4430 Series (70 watts)
Hewlett Packard Pavilion ze4440, ze4443 Series (70 watts)
Hewlett Packard Pavilion ze4450 Series (70 watts)
Hewlett Packard Pavilion ze4453, ze4454, ze4455 Series (70 watts)
Hewlett Packard Pavilion ze4500, ze4501, ze4502 Series (70 watts)
Hewlett Packard Pavilion ze4504, ze4505 Series (70 watts)
Hewlett Packard Pavilion ze4507, ze4508, ze4509 Series (70 watts)
Hewlett Packard Pavilion ze4510, ze4511, ze4512 Series (70 watts)
Hewlett Packard Pavilion ze4513, ze4514, ze4515 Series (70 watts)
Hewlett Packard Pavilion ze4516, ze4518, ze4519 Series (70 watts)
Hewlett Packard Pavilion ze4520, ze4521, ze4522 Series (70 watts)
Hewlett Packard Pavilion ze4523, ze4524, ze4525 Series (70 watts)
Hewlett Packard Pavilion ze4526, ze4530 Series (70 watts)
Hewlett Packard Pavilion ze4540 Series (70 watts)
Hewlett Packard Pavilion ze4545, ze4546, ze4547 Series (70 watts)
Hewlett Packard Pavilion ze4550 Series (70 watts)
Hewlett Packard Pavilion ze4560, ze4565 Series (70 watts)

Hewlett Packard Pavilion ze4600, ze4601 Series (70 watts)
Hewlett Packard Pavilion ze4603, ze4604, ze4605 Series (70 watts)
Hewlett Packard Pavilion ze4610, ze4612 Series (70 watts)
Hewlett Packard Pavilion ze4614, ze4615 Series (70 watts)
Hewlett Packard Pavilion ze4630 Series (70 watts)
Hewlett Packard Pavilion ze4710, ze4718 Series (70 watts)
Hewlett Packard Pavilion ze4720, ze4725 Series (70 watts)
Hewlett Packard Pavilion ze5100 Series (70 watts)
Hewlett Packard Pavilion ze5160, 5165 Series (70 watts)
Hewlett Packard Pavilion ze5170, 5175 Series (70 watts)
Hewlett Packard Pavilion ze5307 Series (70 watts)
Hewlett Packard Pavilion ze5310, ze5315 Series (70 watts)
Hewlett Packard Pavilion ze5320, ze5325 Series (70 watts)
Hewlett Packard Pavilion ze5330, ze5339 Series (70 watts)
Hewlett Packard Pavilion ze5340, ze5343 Series (70 watts)
Hewlett Packard Pavilion ze5344, ze5345 Series (70 watts)
Hewlett Packard Pavilion ze5350, ze5354, ze5357 Series (70 watts)
Hewlett Packard Pavilion ze5360, ze5362, ze5365 Series (70 watts)
Hewlett Packard Pavilion ze5410, ze5413, ze5414 Series (70 watts)
Hewlett Packard Pavilion ze5415, ze5416 Series (70 watts)
Hewlett Packard Pavilion ze5417, ze5418 Series (70 watts)
Hewlett Packard Pavilion ze5420 Series (70 watts)
Hewlett Packard Pavilion ze5425, ze5426, ze5427 Series (70 watts)
Hewlett Packard Pavilion ze5430 Series (70 watts)
Hewlett Packard Pavilion ze5440, ze5443 Series (70 watts)
Hewlett Packard Pavilion ze5445, ze5446, ze5447 Series (70 watts)
Hewlett Packard Pavilion ze5450, ze5451, ze5457 Series (70 watts)
Hewlett Packard Pavilion ze5460, ze5462 Series (70 watts)
Hewlett Packard Pavilion ze5467, ze5468 Series (70 watts)
Hewlett Packard Pavilion ze5477, ze5478 Series (70 watts)
Hewlett Packard Pavilion ze5505, ze5506, ze5507 Series (70 watts)
Hewlett Packard Pavilion ze5510, ze5511, ze5512, ze5513 Series (70 watts)
Hewlett Packard Pavilion ze5514, ze5515, ze5516 Series (70 watts)
Hewlett Packard Pavilion ze5517, ze5518, ze5519 Series (70 watts)
Hewlett Packard Pavilion ze5520, ze5521, ze5522, ze5523 Series (70 watts)
Hewlett Packard Pavilion ze5524, ze5525, ze5526 Series (70 watts)
Hewlett Packard Pavilion ze5527, ze5528, ze5529 Series (70 watts)
Hewlett Packard Pavilion ze5530, ze5531, ze5532, ze5533 Series (70 watts)
Hewlett Packard Pavilion ze5534, ze5535, ze5537 Series (70 watts)
Hewlett Packard Pavilion ze5540, ze5547 Series (70 watts)
Hewlett Packard Pavilion ze5560 Series (70 watts)
Hewlett Packard Pavilion ze5565, ze5568 Series (70 watts)
Hewlett Packard Pavilion ze5570, ze5575 Series (70 watts)
Hewlett Packard Pavilion ze5580, ze5587 Series (70 watts)
Hewlett Packard Pavilion ze5590 Series (70 watts)
Hewlett Packard Pavilion ze5600, ze5601, ze5603 Series (70 watts)
Hewlett Packard Pavilion ze5605, ze5607 Series (70 watts)

Hewlett Packard Pavilion ze5608, ze5609 Series (70 watts)
Hewlett Packard Pavilion ze5610, ze5611, ze5612, ze5613 Series (70 watts)
Hewlett Packard Pavilion ze5614, ze5615, ze5616 Series (70 watts)
Hewlett Packard Pavilion ze5617, ze5618, ze5619 Series (70 watts)
Hewlett Packard Pavilion ze5620, ze5622, ze5623 Series (70 watts)
Hewlett Packard Pavilion ze5624, ze5626 Series (70 watts)
Hewlett Packard Pavilion ze5635, ze5636 Series (70 watts)
Hewlett Packard Pavilion ze5637, ze5638 Series (70 watts)
Hewlett Packard Pavilion ze5640 Series (70 watts)
Hewlett Packard Pavilion ze5645, ze5647 Series (70 watts)
Hewlett Packard Pavilion ze5700 Series (70 watts)
Hewlett Packard Pavilion ze5730, ze5737 Series (70 watts)
Hewlett Packard zu175 Series (70 watts)
Hewlett Packard Pavilion ze4800, ze4801 (70 watts)
Hewlett Packard Pavilion ze4802, ze4803, ze4805 (70 watts)
Hewlett Packard Pavilion ze4815, ze4819 (70 watts)
Hewlett Packard Pavilion ze4820, ze4821, ze4828 (70 watts)
Hewlett Packard Pavilion ze4900, ze4901 (70 watts)
Hewlett Packard Pavilion ze4902, ze4903 (70 watts)
Hewlett Packard Pavilion ze4904, ze4905 (70 watts)
Hewlett Packard Pavilion ze4906, ze4907 (70 watts)
Hewlett Packard Pavilion ze4908, ze4909 (70 watts)
Hewlett Packard Pavilion ze4910, ze4911 (70 watts)
Hewlett Packard Pavilion ze4913, ze4914 (70 watts)
Hewlett Packard Pavilion ze4915, ze4917 (70 watts)
Hewlett Packard Pavilion ze4918, ze4919 (70 watts)
Hewlett Packard Pavilion ze4920, ze4922 (70 watts)
Hewlett Packard Pavilion ze4923, ze4925 (70 watts)
Hewlett Packard Pavilion ze4927, ze4928, ze4929 (70 watts)
Hewlett Packard Pavilion ze4930, ze4931, ze4932 (70 watts)
Hewlett Packard Pavilion ze4933, ze4935, ze4936 (70 watts)
Hewlett Packard Pavilion ze4937, ze4938, ze4939 (70 watts)
Hewlett Packard Pavilion ze4940, ze4941, ze4942 (70 watts)
Hewlett Packard Pavilion ze4943, ze4944, ze4945 (70 watts)
Hewlett Packard Pavilion ze4947, ze4948, ze4949 (70 watts)
Hewlett Packard Pavilion ze4950, ze4951, ze4954 (70 watts)
Hewlett Packard Pavilion ze4955, ze4956, ze4958 (70 watts)
Hewlett Packard Pavilion ze4960, ze4962, ze4965 (70 watts)
Medion MD6001

CO1507

Voltagem: 19 volts

Amperagem: 3,16 ampères

Potência: 60,04 watts

Modelos de notebooks compatíveis com este código (148 modelos disponíveis)

Compaq Business NoteBook NX9000 (57 watts)
Compaq Business NoteBook NX9005 (57 watts)
Compaq Business NoteBook NX9010 (57 watts)
Compaq Evo N105
Compaq Evo N115
Compaq Evo N160
Compaq Evo N180
Compaq Presario 1010, 1020, 1030, 1040
Compaq Presario 1060, 1065, 1070, 1072, 1075
Compaq Presario 1080, 1082, 1084, 1090
Compaq Presario 1200, 1200T
Compaq Presario 1200XL
Compaq Presario 1207, 1210, 1215, 1220
Compaq Presario 1230, 1232, 1235, 1236, 1237
Compaq Presario 1240, 1245, 1247
Compaq Presario 1250, 1255, 1260, 1266, 1267
Compaq Presario 1270, 1272, 1275, 1277, 1279
Compaq Presario 12XL 101, 103, 104, 106, 109
Compaq Presario 12XL 110, 111, 112, 113, 114
Compaq Presario 12XL 201, 202, 204, 206
Compaq Presario 12XL 211, 212
Compaq Presario 12XL 220, 222, 223
Compaq Presario 12XL 300, 301, 302, 303, 305, 307
Compaq Presario 12XL 310, 311, 312, 314
Compaq Presario 12XL 320, 323, 325, 326, 327, 330
Compaq Presario 12XL 400, 401, 403, 405, 406, 408, 409
Compaq Presario 12XL 410, 411, 414, 416
Compaq Presario 12XL 420, 421, 423, 426, 427, 428, 430
Compaq Presario 12XL 500, 501, 502, 504, 505, 506, 509
Compaq Presario 12XL 510, 512, 513, 515, 517, 519
Compaq Presario 12XL 520, 521, 526, 527, 530, 531
Compaq Presario Série 12XL
Compaq Presario Série 1400
Compaq Presario 1400EB
Compaq Presario 1400T
Compaq Presario 1400T, 1400T-XL4
Compaq Presario 14XL 240, 241, 242, 244, 245, 246
Compaq Presario 14XL 247, 250, 340, 342, 346
Compaq Presario 14XL 350, 352, 355, 356
Compaq Presario 14XL 420, 440, 442, 445, 446, 447
Compaq Presario 14XL 452, 453, 454, 455
Compaq Presario Série 14XL
Compaq Presario 1600
Compaq Presario 1600, 1610, 1620, 1621, 1622
Compaq Presario 1600T

Compaq Presario 1600XL
Compaq Presario 1625, 1640, 1650, 1655, 1670
Compaq Presario 1680, 1681, 1685, 1688
Compaq Presario 1690, 1692, 1693, 1694
Compaq Presario 16XL 140, 141, 142, 144, 145, 146, 147
Compaq Presario 16XL 150, 255, 256, 257, 258
Compaq Presario 16XL
Compaq Presario 1700
Compaq Presario 1700, 1701, 1702, 1703, 1704, 1705
Compaq Presario 1710, 1711, 1712, 1713, 1714
Compaq Presario 1715, 1716, 1717, 1720
Compaq Presario 1721, 1722, 1723, 1724, 1725
Compaq Presario 17XL 260, 262, 264, 265, 266
Compaq Presario 17XL 274, 275
Compaq Presario 17XL 360, 361, 364, 365, 366, 368, 369
Compaq Presario 17XL 378, 379, 380
Compaq Presario 17XL 460, 461, 462, 463, 464, 466
Compaq Presario 17XL 468, 469, 470, 471, 472, 473
Compaq Presario 17XL 474, 475, 476, 477, 480
Compaq Presario 17XL 482, 485, 488, 490, 492
Compaq Presario 17XL 561, 562, 563, 565, 567, 568
Compaq Presario 17XL 571, 572, 573, 577, 579, 580
Compaq Presario 17XL
Compaq Presario 17XL2
Compaq Presario 1800
Compaq Presario 1800, 1810, 1820, 1825, 1827, 1830
Compaq Presario 1800T
Compaq Presario 1800XL
Compaq Presario 18XL 181, 181, 182, 183, 185, 186
Compaq Presario 18XL 280, 281, 380, 381, 390
Compaq Presario 18XL 481, 482, 483, 484, 485
Compaq Presario 18XL 580, 581, 583, 584, 585
Compaq Presario 18XL 586, 590
Compaq Presario 18XL
Compaq Presario 18XL2
Compaq Presario 2100 (Fonte de 57 watts)
Compaq Presario 2100T, 2100US, 2100Z
Compaq Presario 2101, 2102, 2103, 2104
Compaq Presario 2105, 2106, 2107, 2108, 2109
Compaq Presario 2110, 2111, 2112, 2113, 2114
Compaq Presario 2115, 2116, 2117, 2118, 2119
Compaq Presario 2120, 2121, 2122, 2123, 2124
Compaq Presario 2125, 2126, 2127, 2128, 2129
Compaq Presario 2130, 2131, 2132, 2133, 2134
Compaq Presario 2135, 2136, 2137, 2138, 2139
Compaq Presario 2140, 2141, 2142, 2143, 2144
Compaq Presario 2145, 2146, 2147, 2148, 2149

Compaq Presario 2150, 2151, 2152, 2153, 2154
Compaq Presario 2155, 2156, 2157, 2158, 2159
Compaq Presario 2160, 2161, 2162, 2163, 2164
Compaq Presario 2165, 2166, 2167, 2168, 2169
Compaq Presario 2170, 2171, 2172, 2173, 2174, 2175
Compaq Presario Série 2500
Compaq Presario 2510, 2511, 2512, 2515, 2516
Compaq Presario 2520, 2521, 2525, 2526, 2528
Compaq Presario 2530, 2535, 2538
Compaq Presario 2540, 2545, 2550, 2555
Compaq Presario 2560, 2565, 2570, 2575
Compaq Presario 2700, 2700AP, 2700EA, 2700GR
Compaq Business NoteBook N1050v Series
Compaq Business NoteBook NX9008 Series
Compaq Evo Série N1050v
Compaq Presario 2175, 2176, 2177, 2178, 2179
Compaq Presario 2180, 2181, 2182, 2183, 2184
Compaq Presario 2185, 2186, 2187, 2188, 2189
Compaq Presario 2190, 2191, 2192, 2193
Compaq Presario 2195, 2197, 2198, 2199
Compaq Presario 2505, 2507, 2508, 2509
Compaq Presario 2515, 2516, 2517, 2518, 2519
Compaq Presario 2525, 2526, 2527, 2528, 2529
Compaq Presario 2535, 2536, 2537, 2538, 2539
Compaq Presario 2545, 2546, 2547, 2548, 2549
Compaq Presario 2700LA, 2700T, 2700TC, 2700US
Compaq Presario 2701, 2701EA, 2701T, 2701US
Compaq Presario 2702, 2702EA
Compaq Presario 2710, 2710CA, 2710EA
Compaq Presario 2710SC, 2710TC, 2710US
Compaq Presario 2711, 2711AP, 2711EA, 2711TC
Compaq Presario 2712, 2712EA, 2712TA
Compaq Presario 2715, 2715EA, 2715US
Compaq Presario 2716, 2716EA
Compaq Presario 2720, 2720CA, 2720EA, 2720US
Compaq Presario 2550, 2551, 2552, 2553, 2554
Compaq Presario 2555, 2556, 2567, 2558, 2559
Compaq Presario 2560, 2561, 2562, 2563, 2564
Compaq Presario 2565, 2566, 2567, 2568, 2569
Compaq Presario 2570, 2571, 2572, 2573, 2574
Compaq Presario 2575, 2576, 2577, 2578, 2579
Compaq Presario 2580, 2581, 2582, 2583, 2584
Compaq Presario 2585, 2586, 2587, 2588, 2589
Compaq Presario 2590, 2591, 2592, 2593, 2594
Compaq Presario 2595, 2596, 2597, 2598, 2599
Compaq Presario 1110, 1110DE, 1110GR, 1110IT, 1110UK
Compaq Presario 1115, 1115GR, 1115IT

Compaq Presario 1120, 1120IT
Compaq Presario 16XL 140, 141, 142, 144, 145, 146, 147
Compaq Presario 700 Series
Compaq Presario 700, 701, 702, 703, 704, 705, 706, 709
Compaq Presario 710, 711, 712, 713, 714, 715, 716, 717
Compaq Presario 718, 719, 720, 721, 722, 723, 724, 725
Compaq Presario 726, 727, 728, 729, 730, 731, 732, 733
Compaq Presario 734, 735, 736, 737, 739, 739
Compaq Presario Série 80XL4

TI1506

Voltagem: 19 volts

Amperagem: 3,16 ampères

Potência: 60,04 watts

Modelos de notebooks compatíveis com este código (1477 modelos disponíveis)

Accel AccelNote CY23

Accel AccelNote CY25

Accel AccelNote N341

Actebis Targa Companion

Actebis Targa Visionary 1300

Actebis Targa Visionary 1600

Actebis Targa Visionary 1800

Actebis Targa Visionary 1900

Actebis Targa Visionary I

Actebis Targa Visionary II

Actebis Targa Xtender 400

Actebis Targa Xtender 500

Advent 2410

Advent 340S2

Advent 3480DVD

Advent 4470

Advent 4480, 4480DVD

Advent 5372, 5372DVD

Advent 540DVD

Advent 5480, 5480DVD

Advent 5490

Advent 6410

Advent 6411

Advent 6412, 6412DVD

Advent 6413, 6413A

Advent 6414, 6414B

Advent 6415, 6415X, 6415XP

Advent 6416, 6417

Advent 6418, 6418XP

Advent 6419, 6419XP
Advent 6421, 6422
Advent 6520, 6521, 6522
AJP 3420
AJP 7170
AJP 7321
AJP 7521
AJP 8080
AJP M722
Alphatop Green 320
Alphatop Green 550
Alphatop Green 551
Alphatop Green 552
Alphatop Green 553
Alphatop Green 556
Alphatop Green 556e
Alphatop Green 720
Alphatop G320
Alphatop G550
Alphatop G551
Alphatop G552
Alphatop G556
Alphatop G556e
Alphatop G553
Alphatop G720
Alphatop G799
ALR Evolution
AMS Rodeo 1000CT
AMS Rodeo 1010CT
Arima CP10-S
Arima CP10V
Arm Computer ArmNote 340S
Arm Computer ArmNote 340S2
Arm Computer ArmNote 340S8
Arm Computer ArmNote 7521P Series
Arm Computer ArmNote CY23
Arm Computer ArmNote CY25
Arm Computer ArmNote CY27
Arm Computer ArmNote M722
Arm Computer ArmNote N30N3
Arm Computer ArmNote N341C2
Arm Computer ArmNote N38W, N38W2
Arm Computer ArmNote N38W3
Arm Computer ArmNote TS30W, TS30W2
Ashton Digital MaxiNote 400
Ashton Digital MaxiNote 420
Ashton Digital Green 710

Ashton Digital MaxiNote 420
Asus A1 Series
Asus A1000 Series
Asus A2, A2L Series
Asus A2000, A2000L Series
Asus F7, F7B Series
Asus F74, F74B Series
Asus F7400, F7400B Series
Asus L1, L1B Series
Asus L2, L2E Series
Asus L2000, L2000E Series
Asus L3, L3C, L3H Series
Asus L3000, L3000C, L3000H Series
Asus L3100 Series
Asus L31, L32, L34, L35 Series
Asus L3200 Series
Asus L1000, L1000B Series
Asus L3400 Series
Asus L3500, L3500D, L3500Tp Series
Asus L3800, L3800C Series
Asus L4000, L4000H Series
Asus L4, L4H Series
Asus L7 Series
Asus L7000, L7000B, L7000C Series
Asus L7000D, L7000E Series
Asus L7000G, L7000H Series
Asus L7B, L7C, L7D Series
Asus L7E, L7G, L7H Series
Asus L8 Series
Asus L8000 Series
Asus L84 Series
Asus L8400, L8400B, L8400C Series
Asus L8400Ce Series
Asus L8400F, L8400K, L8400L Series
Asus L84B, L84C, L84F Series
Asus L84K, L84L Series
Asus M2, M2E, M2N Series
Asus M2000, M2000E Series
Asus M2000, M2000N Series
Asus M3, M3N Series
Asus M3000, M3000N Series
Asus M5, M5N Series
Asus M5000, M5000N Series
Asus M6, M6N, M6Ne, M6R Series
Asus M6000, M6000N, M6000R Series
Asus S1, S1A, S1B, S1N Series
Asus S1000, S1000A Series

Asus S1000B, S1000N Series
Asus S1300 Series
Asus S5, S5N Series
Asus S5000, S5000N Series
Asus S8, S8A Series
Asus S8000, S8000A Series
Asus S82, S82A Series
Asus S8200, S8200A Series
Asus S86, S86A Series
Asus S8600, S8600A Series
Asus Z9, Z9R Series
Asus Z90, Z90R Series
Asus Z9000, Z9000R Series
Avant Technologies NewGate G799
Averatec 5100 Series
Averatec 5110 series
Averatec 5110H, 5110HX, 5110P
Baycom 2200 Series
Baycom 2700 Series
Baycom 2850 Series
Baycom Agent PGA1
Baycom Agent PGA2
Baycom Voyage
Baycom WorldBook
Baycom WorldBook 1, WorldBook 2
Baycom WorldBook 3, WorldBook 3 Plus
Bliss 2060
Boldata BolData N341C2
Brick Computer Mobile Warrior M300N
Brick Computer Preceptor 4
Brick Computer Preceptor 5 (CY27)
Brick Computer RocketBrick (N30N3)
Brick Computer RocketBrick Plus (CY23)
Brick Computer RocketBrick2A (N341C2)
Brick Computer SpeedBrick (TS30W)
Brick Computer SpeedBrick Plus (TS30W2)
Brick Computer SpeedBrick Plus 3 (TS30W3)
Bullman Aero 3-14
CA Technologies Eagle T15II
California Access G553 Manta
Canon InnovaBook 475CDS, 475CDT
Cat Eagle T15II
Centerprise CP10-S
Centerprise CP10V
Chem USA ChemBook 3015E
Chem USA ChemBook 3470
Chem USA ChemBook 3815

Chem USA ChemBook 3830, 3830A
Chem USA ChemBook 4025
Chiligreen Dynamic D4-22ES
Chiligreen Dynamic D4-22ES WS
Chiligreen Mobilitas CT C5-375E
Chiligreen Mobilitas CT C5-G553
Chiligreen Mobilitas CT C5-G556
Clevo DeskNote 2200, 2200C, 2200T
Clevo DeskNote 2700, 2700C, 2700T
Clevo MobiNote 3220
Clevo MobiNote 3420
Clevo MobiNote 3620
Clevo MobiNote M220S
Clevo MobiNote M22ES
Clevo MobiNote M270S
Clevo MobiNote M27ES
Clevo MobiNote M300N
Clevo MobiNote M310N
Clevo MobiNote M350B
Clevo MobiNote M350C
Clevo MobiNote M360B
Clevo MobiNote M360C
Clevo MobiNote M361C
Clevo MobiNote M362C
Clevo MobiNote M375C
Clevo MobiNote M375E
Clevo MobiNote M375EW
Clevo MobiNote M37EW
Clevo MobiNote M385C
Clevo 2200, 2200C, 2200T
Clevo 2700, 2700C, 2700T
Clevo 2800, 2800T
Clevo 2820
Clevo 2830
Clevo 2850
Clevo 3220
Clevo 3420
Clevo 3620
Clevo 86, 86CE
Clevo 862
Clevo 863
Clevo D220S
Clevo D22ES
Clevo D270S
Clevo D27ES
Clevo M220S
Clevo M22ES

Clevo M270S
Clevo M27ES
Clevo M300N
Clevo M310N
Clevo M350B
Clevo M350C
Clevo M360B
Clevo M360C
Clevo M361C
Clevo M362C
Clevo M375C
Clevo M375E
Clevo M375EW
Clevo M37EW
Clevo M385C
Clevo PortaNote 2200, 2200C, 2200T
Clevo PortaNote 2700, 2700C, 2700T
Clevo PortaNote 2820
Clevo PortaNote 2830
Clevo PortaNote 2850
Clevo PortaNote D220S
Clevo PortaNote D22ES
Clevo PortaNote D270S
Clevo PortaNote D270S
Clevo PortaNote D27ES
Clevo Ultimate Plus 2820
Clevo Ultimate Plus 2830
Clevo Ultimate Plus 2850
Clevo Ultimate Traveler 3220
Clevo Ultimate Traveler 3420
Clevo Ultimate Traveler 3620
Compal N30N3
Compal 888M1
Compal BCY27
Compal BTK20
Compal BTW10
Compal CY20, CY23
Compal CY25
Compal CY27
Compal N30W
Compal N30W2
Compal N30W3
Compal N32NC
Compal N38W2, N38W3
Compal TS30W
Compaq Presario Série 800, 800T, 800XL
Compaq Presario Série 80XL200, 80XL201

Compaq Presario Série 80XL4, 80XL4S
Compaq Presario Série 80XL550
Compower CY25
Compower N30N3
Compower N30W
Compower TS30H
Compuadd NBE/S
Computek DesigNote G550
CTX EzBook 300
CTX EzBook 330F, 330S, 330T
CTX EzBook 350D, 350F, 350T, 350S
CTX EzBook 360D, 360F, 360S, 360T
CTX EzBook 364D, 364F, 364T
CTX EzBook 372D, 372T, 374D, 374T
CTX EzBook 377D, 377T, 390T
CTX EzBook 400, 400T
CTX EzBook 500, 500T
CTX EzBook 700, 700C
CTX EzBook 700E
CTX EzBook 700M
CTX EzBook 720CS, 722CS, 725CS
CTX EzBook 730CS, 730CDT, 750CS, 750CDT
CTX EzBook 750MS, 750MT, 760MS, 760MT
CTX EzBook 764MS, 764MT
CTX EzBook 770MS, 770MT, 772MS, 772MT
CTX EzBook 774MS, 774MT, 777MS, 777MT
CTX EzBook 800
Cybercom CC5061
Cybercom CC5214
Cybercom CC5218
Cybercom CC5222
Cybercom CC5223
Cybercom CC5225
Cybercom CC5389
Cybercom CC5400
Cybercom CC5498
Cybercom CC5499
Cybercom CC5943
Cybercom CC5944
Cybercom CC5945
Cybercom CC5946
Cybercom CC6181
Cybercom CC7321
Cybercom CC9373
Cybercom CC9467
Cybercom CC9580-A
Cybercom CC9580-F

Cybercom CC9628
Cybercom CC9695
Cybercom CC9703
Cybercom CC9787
Cybercom CC9788
Cybercom CC9799
Cyclone CP10-S
Cyclone CP10V
DEC HiNote TS30H
DEC HiNote VP 700, 703, 710, 717
DEC HiNote VP 725, 735, 745, 765
Dell Inspiron 1000 Series
Dell Inspiron 3000 M233ST, M266XT
Dell Inspiron 3000 Series
Dell Inspiron 3200 Series
Detel CY25
DFI NB6600, NB6620
Diablo DayLine DL550
Diablo Dive DV30
Diablo DayLine DL680 Plus
Digital HiNote TS30H
Digital HiNote VP 700, 703, 710, 717
Digital HiNote VP 725, 735, 745, 765
DTK MaxForce 8080
E-Max IS340S2
E-Max IS6340S2
E-Max 340S2
ECS G320
ECS G550
ECS G551
ECS G552
ECS G553
ECS G556
ECS G556e
ECS G720
ECS G799
ECS Green 320
ECS Green 550
ECS Green 551
ECS Green 552
ECS Green 553
ECS Green 556
ECS Green 556e
ECS Green 720
ECS Green 799
ECS Green G320
ECS Green G550

ECS Green G551
ECS Green G552
ECS Green G553
ECS Green G556
ECS Green G556e
ECS Green G720
ECS Green G799
ECS Precision 2000 SlimNote G550
Elements MB05
Enface Ethane 220
Enface Ethane 270
Enface Ethane 3220
Enface Ethane 360C
Enface Ethane D270
Enface Octave 2820
Enface Octave 2820-50
Enface Octave 2850
Enpower N341C2
Epson ActionNote 800, 866C, 880C, 880CX
Epson ActionNote 890, 890C, 895C
Epson ActionNote 910C
Ergo RocketBrick (N30N3)
Ergo RocketBrick 2A (N341C2)
Ergo RocketBrick Plus (CY23)
Ergo SpeedBrick Plus 3 (TS30W3)
Ergo SpeedBrick (TS30W)
Ergo SpeedBrick Plus (TS30W2)
ETC Eurotech ETC 7520
Eurocom 2200, 2200C, 2200T
Eurocom 2700, 2700C, 2700T
Eurocom 3420 Series
Eurocom M270S Series
Eurocom M270S Viper M
Eurocom M350C Milano
Everex StepNote 3500 Series
Everex StepNote Plus
Everex StepNote SR Series
Everex MB02
Everex MB05
Excel SlimNote G550
Excel SlimNote G551
Excel SlimNote G553
Excel SlimNote G556
F.I.C. 20
F.I.C. 30
F.I.C. 56
F.I.C. 57

F.I.C. A40
F.I.C. A440
F.I.C. A3
F.I.C. 2000
F.I.C. A320
F.I.C. A320 Plus
F.I.C. A360
F.I.C. A360 Plus
F.I.C. A380
F.I.C. A385
F.I.C. A386
F.I.C. A40
F.I.C. A420, A430
F.I.C. A440
F.I.C. A45, A45 Plus
F.I.C. A450, A450 Plus
F.I.C. A455
F.I.C. A46
F.I.C. A460, A460L
F.I.C. A5
F.I.C. A550
F.I.C. A560
F.I.C. A985
F.I.C. A985L
F.I.C. L4
F.I.C. LE4
F.I.C. M2 Series
F.I.C. M285
F.I.C. M288
F.I.C. MB02
F.I.C. MB05, MB05 Plus
F.I.C. MB05C, MB05H
F.I.C. MB05M, MB05P
F.I.C. MB05T
F.I.C. MB05W, MB05W Plus
F.I.C. MBO2
F.I.C. WaveLight Box Office 340
F.I.C. WB-B55
F.I.C. WB-B55-C
Fortune 2700D
Fortune M350C
Fortune M375C
Fortune M375E
Fortune Freedom CY27
Fortune Freedom N341C2
Fosa 340S2
Fosa N340S2

Fosa N340S8
Fosa 2200, 2200C, 2200T
Fosa 2700
Fosa 30N3, 30N3L
Fosa 3220
Fosa 340S
Fosa 341C2
Fosa 3420
Fosa CY20, CY23
Fosa CY25
Fosa CY27
Fosa N340S2
Fosa N340S8
Fujitsu Amilo M
Fujitsu Amilo M-3100, M-4100, M-4500, M-6100
Fujitsu Amilo M-6500
Fujitsu LifeBook 30N3
Fujitsu LifeBook C-1010, C-1020
Fujitsu LifeBook C-1110, C-1110D
Fujitsu LifeBook C-6597
Fujitsu LifeBook C-6637
Fujitsu LifeBook C1010, C1020
Fujitsu LifeBook C1110, C1110D
Fujitsu LifeBook C1110, C1110D
Fujitsu LifeBook FMV FM-4
Fujitsu LifeBook FMV-612NU2/E
Fujitsu Amilo A
Fujitsu Amilo D 5100, D 5500
Fujitsu Amilo D 6100, D 6500
Fujitsu Amilo D 7100, D 7500
Fujitsu Amilo D-5100, D-5500
Fujitsu Amilo D-6100, D-6500
Fujitsu Amilo D-7100, D-7500
Fujitsu Amilo D6100, D6500
Fujitsu Amilo D7100, D7500
Fujitsu Amilo M-6300
Fujitsu Amilo M-6800
Fujitsu Amilo M-7300
Fujitsu Amilo M-7800
Fujitsu Amilo M-8300
Fujitsu Amilo M-8800
Fujitsu Amilo M3100, M4100, M4500
Fujitsu Amilo M6100
Fujitsu Amilo M6300
Fujitsu Amilo M6500
Fujitsu Amilo M6800
Fujitsu Amilo M7300

Fujitsu Amilo M7800
Fujitsu Amilo M8300
Fujitsu Amilo M8800
Gateway 2000 Solo Série 1100
Gateway 2000 Solo Série 1150
Gateway 2000 Solo Série 1200
Gateway 2000 Solo 1400 Series
Gateway 2000 Solo 1450 Series
GEO Microsystems Focus 250
Gericom Blockbuster Mobile
Gericom Cinema
Gericom GigaBook A430, A440, A450
Gericom HydroSpeed
Gericom Millennium 2, Millennium 3
Gericom Millennium II, Millennium III
Gericom 2000
Gericom 2200C, 2200S, 2200T
Gericom 3220
Gericom 3420
Gericom 3620
Gericom A360
Gericom A360
Gericom A380
Gericom A385
Gericom A386
Gericom A430, A440, A450
Gericom A550 (Genio)
Gericom G550
Gericom G551
Gericom G552
Gericom G553
Gericom G556
Gericom Genio MSW (A5, A550)
Gericom N30W
Gericom N38W2, N38W3
Gericom NB2000
Gericom T3 Series
Gericom Overdose 2200C
Gericom Overdose 3
Gericom Overdose III
Gericom Overdose Radeon 9600
Gericom Overdose Radeon 9700
Gericom Overdose Radeon MC G551
Gericom Overdose S
Gericom Overdose S2, Overdose S3
Gericom Overdose T
Gericom Overdose T1130

Gericom Overdose XL Per4mance G550
Gericom Silver Shadow
Gericom Silver Shadow 2
Gericom Silver Shadow II
Gericom 1st SuperSonic
Gericom 1st Supersonic GPRS
Gericom 1st Supersonic M6-T
Gericom 1st Supersonic P4
Gericom SuperSonic
Gericom SuperSonic 1000
Gericom SuperSonic 2
Gericom SuperSonic II
Gericom Supersonic Per4mance
Gericom Supersonic Performance
Gericom Webboy
Gericom Webgine
Gericom Webgine Advanced
Gericom Webgine Advanced XL
Gericom Webgine MSE
Gotcha CopyBook 533, 533TX
Gotcha CopyCat FSM
Greennote Green G720
GVS Computers 8080
GVS Computers D270, D270E, D270S
H@kers CY23
H@kers CY25
H@kers N30N3
Highlander HighLander HL-30, HL- 31, HL-31TH
Highlander HighLander HL-340s2 HL-340s8
Highlander HighLander HL-342
Highlander HighLander HL-38
Highlander HighLander HL-68
Highlander HighLander HL-N30N
Hitachi Prius Note 200A
Hitachi Prius Note 200B4TM
Hitachi Prius Note 200C4TMD
Hitachi Flora 270SX NH8
Hundyx 7200
Hundyx HU D27ES
Hyperdata MediaGo Série 2300
Hyperdata MediaGo Série 2310
Hyperdata MediaGo Série 2320
Hyperdata MediaGo Série 2800
Hyperdata MediaGo Série 3800
Hyperdata CQ60, CQ62, CQ70
Hyperdata MediaGo 1200 Series
Hyperdata MediaGo 2700 Series

Hyperdata MediaGo 2710 Series
Hyperdata MediaGo 2730 Series
Hyperdata MediaGo 2750 Series
Hyperdata MediaGo 798 Series
Hyperdata 2500